

## TOPRITE WORKTOPS

### DUROPAL MATCHING ABS/ PP EDGINGS

U11026 MS Crystal White U1026  
U11027 XM Icy White U1027  
U12188 XM Light Grey  
R20004 VV Natural Oak Block R4101  
R20016 VV Harvard Oak Block R4210  
R20039 RU Sonoma Oak R4285  
R20065 NW Dark Mountain Oak R4371  
R20090 RU Lambrate R5836  
R24022 VV White Beech Parquet R5336  
R30023 VV Block Walnut R5151  
R30027 VV Woodmix Block R5989  
R45004 VV Plum Butcherblock R5638  
R50003 RU Clay Sangha Wenge R5612  
R50004 RU Nat Sangha Wenge R5613  
R55004 RU Ponderosa Pine  
S61000 FG Grey Ottawa R6050  
S61001 FG Brown Ottawa R6052  
S61008 TC Black Brazil R6216  
S61011 CT Ipanema White R6265  
S61013 CT Ipanema Grey R6267  
S62008 VV Brown Sahara R6457  
S62009 CT Natural Messina R6461  
S62010 CT Antique Messina R6462  
S62011 CT Taurus Sand R6482  
S63003 TC Light Marble R6254  
S63011 TC Jura Marble R6442  
S63014 HS Roma Marble Gloss R6499  
S64004 FG Welsh Slate R6487  
S66000 TC Star Black F7407  
S66010 TC Mirabelle Corro R6352  
S66012 MS Glacial Storm R6480  
S68000 TC Anthracite Peru F7646  
S68002 TC Astral Quartz F8345  
S68002 HS Astral Quartz Gloss F8345  
S68004 CT Tivoli R6244  
S68013 TC Black Limestone R6424  
F73009 CT Quartz Stone F7655  
F73010 TC Dark Anthracite Fino F7684  
F76016 CT Flash Black F7654  
F76023 VV Brushed Aluminium F8110  
F76044 XM Bellato Grey

Duropal pattern numbers have been changed and now have five numbers. The old code is shown in blue.

The texture on the PP/ABS edge is not always the same as the texture of the worktop

Updated February 2018